

QWIZDOM Q6*i* INSTRUCTOR REMOTE

Menu/Power: Press and hold to turn remote on/off. Press to view menu options: , *Enter Sess. ID*, *Enter User ID*, and *Backlight*.

Directional Arrows: Press to navigate between slides and press (↵) to select LCD menu choices.

Full List: View all available actions.

② **Private LCD Graph:** Display a response graph on the Instructor Remote's LCD.

③ **Public Screen Graph:** Display the response graph for everyone to view.

⑤ **Help Menu:** Display a list of participants who request help.

⑥ **New Q:** Pose a spontaneous question.

Shift: Changes case options: *ABC/Abc/abc/123/Superscript/Subscript*.

① **Pick:** Randomly call on a participant.

④ **Re-pose Question:** Re-pose the current question slide.

Symbols: Press to enter fraction, punctuation, etc.

⑦ **Pick (Special):** Select a participant at random from a specific group. Groups include answered correctly, not called on, etc.

