


Connect: Remote Assignment

NOTE: New Q2, Q4, and Q6 users do *not* have to go through this process.

1. Insert the black USB host into the USB port of your computer.
2. Click on the Qwizdom Tools icon  (bottom of your computer screen).
3. In the Tools window, click **Utilities**, then **Remote Assignment**.

NOTE: A Session ID will appear at the top of the Tools window. This is your host's unique 6-digit identifier.


4. In the Remote Assignment window, click **Detect**.

The **Session ID** will appear in the text field.

5. Check the box for Auto-Increment Remote Number.

6. Click **Start**.

7. Turn on remotes one at a time.



When a remote connects with the host, its assigned number will appear on the remote's display. If remotes do not connect, they are not configured with the correct Session ID. Please refer to the Full User Guide to change Session ID.

8. Click **Stop** when all remotes have been assigned.

Your remotes will turn off automatically.



This process only needs done once—the assigned number will remain fixed with that remote. If desired, use a marker, or affix a sticker, to designate the number that has been assigned.