

# QWIZDOM Q4 REMOTE

- 1 Q#:**  
Displays the current question number.
- 2 Right/Wrong Feedback:**  
Indicates the submitted response was: correct (✓), incorrect (X), or received (✓ X).
- 3 Menu/Power:**  
Press and hold to turn remote on/off.  
Press to view menu options: *Help, Search, Sess. ID, User ID, and Exit.*
- 4 Send:**  
Press to submit answer, select a menu option, and confirm *Session* or *User ID*.
- 5 Decimal:**  
Press between two numbers to indicate a decimal.




- 6 ID#:**  
Displays the remote ID number.
- 7 Battery Power:**  
Appears when battery is low.
- 8 Left/Right Arrows:**  
Press to navigate between menu options, answer choices, and questions (when in paper-based mode).
- 9 Clear:**  
Press to delete the last character or change answer (when allowed).
- 10 Fraction:**  
Press between two numbers to indicate a fraction.
- 11 Minus:**  
Press to indicate a negative number.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## COMMON LCD SCREEN DISPLAYS

QWIZDOM Inc © 2010



Remote is waiting for *Session ID #*.



Remote is loading an *Answer Key*; this may take a few moments.



Remote senses the host is not in use, or does not recognize the *Session*. If remote remains inactive after starting a presentation, follow steps to the left to change the *Session ID*.



Remote is waiting for the *User ID #*.

### To change *Session ID*:

- Press *Menu*.
- Press the *Right Arrow* key once.
- Press *Send*.
- If the *Session ID* is incorrect, press *Yes/T*.
- Enter the correct *Session ID* and then press *Send*.



User denied due to incorrect *Session ID*, *User ID*, or a duplicate ID. Follow steps to the left to double check *Session ID* and/or *User ID*.



Remote is searching for the *Host*.

### To change *User ID*:


- Press *Menu*.
- Press the *Right Arrow* key twice.
- Press *Send*.
- If the *User ID* is incorrect, press *Yes/T*.
- Enter the correct *User ID* and then press *Send*.



Remote cannot find the host due to an incorrect *Session ID* or *User ID*. Follow the steps to the left to change *Session ID*.




Remote has found the *Host* and is waiting for a question slide.



Remote is idle. Press any key, except the *Menu* key to reactivate.



Press *Send* to privately ask for help or scroll to *Exit* using the *Right Arrow* key and then press *Send*.



Remote is requesting an *Answer Key* activity # (only shows when multiple *Answer Keys* are used).