

QWIZDOM Q6 REMOTE

- 1 Q#:**
Displays the current question number.
- 2 Help Request:**
Indicates you requested help.
- 3 Right/Wrong Feedback:**
Indicates the submitted response was: correct (✓), incorrect (X), or received (✓ X).
- 4 Menu/Power:**
Press and hold to turn remote on/off.
Press to view menu options: *Help, Search, Sess. ID, User ID, Adjust Contrast, and Exit.*
- 5 Enter:**
Press to submit commands from LCD menu choices.
- 6 Symbols:**
Press to enter fractions, punctuation, etc.




- 7 ID#:**
Displays remote ID number.
- 8 Battery Power:**
Displays battery charge.
- 9 Multi-function:**
Serves as a multifunction for Send/Change.
- 10 Directional Arrows:**
Press to navigate between menu options, answer choices, and questions (when in paper-based mode).
- 11 Shift:**
Changes case options: *ABC/Abc/abc/123/Superscript/Subscript.*
- 12 Delete:**
Press to delete the last character.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

COMMON LCD SCREEN DISPLAYS


QWIZDOM Inc © 2010



Remote is waiting for *Session ID* #.



Remote is waiting for the *User ID* #.



Remote cannot find the host due to an incorrect *Session ID*. Follow the steps to the left to change *Session ID*.




Help is the first Menu option. With *Help* selected, press (↵) *Enter* to ask for help privately or scroll to *Exit* and press (↵) *Enter*.

To change *Session ID*:


- Press *Menu*.
- Using the *Down Arrow*, scroll to *Enter Session ID*.
- Press (↵) *Enter*.
- If the *Session ID* is incorrect, re-enter the *Session ID*.
- Press *Join* to submit.

To change *User ID*:

- Press *Menu*.
- Using the *Down Arrow*, scroll to *Enter User ID*.
- Press (↵) *Enter*.
- If the *User ID* is incorrect, re-enter the *User ID*.
- Press *Join* to submit.




User denied due to incorrect *User ID* or a duplicate ID. Follow steps to the left to change *User ID*.




Remote is searching for the *Host*.




Remote is loading an *Answer Key*; this may take a few moments.



Remote has found the *Host* and is waiting for a question slide.



Remote is idle. Press *Resume* to reactivate.



Remote is requesting an *Answer Key* activity # (only shows when multiple *Answer Keys* are used.)